

AXROMA Outdoor Performance Fabrics / Maintenance and Cleaning Instructions

AXROMA Outdoor Performance Fabrics quality warranty: officially 3 years of quality assurance, but it could reach 5 to 7 years under the appropriate maintenance. After washing, the water repellency will be reduced, but it will not disappear, and its protective essences can be repaired easily.

Routine Cleaning

1. Before cleaning, pull up all zippers, buckle all buttons, Velcros on, and prepare a soft brush for next steps.
2. Use a soft brush gently to wipe off dusts, or other attachments on the fabrics.
3. Wash off the dust and dirt on the fabric with water or soak the fabrics in the water.
4. The neutral detergent needs to be diluted (1:5). The water temperature should be lower than 30°C, which will help to quicken the decomposition of stains.
5. Brushing with water till no foam on the fabric.
6. Keep the fabric air dry.





Deep Cleaning (Bleaching)

1. Before cleaning, pull up all zippers, buckle all buttons, Velcros on, and prepare a soft brush for next steps.
2. Use a soft brush gently to wipe off dusts, or other attachments on the fabrics.
3. Wash out with water, then add the diluted bleach in a small spot first to ensure the best effects.
4. Stubborn stains could be soaked in the diluted detergent (1:50) for 5-10 minutes; this will help to quicken the decomposition of stains.
5. Brushing with water till no foam on the fabric.
6. Keep the fabric air dry.

Friendly Reminder:

1. The best tools for cleaning the fabrics are the soft brush, or a clean white towel.
2. Keep fabrics away from heat and flame.
3. Keep fabrics away from oil which will block the air-permeable micro pores and cause molds so to affect the fabrics' performance.
4. Various fabrics have different structures and textures; do not excessively stretch fabrics while using.
5. For the fabric with wrinkles, ironing it with low temperature is allowed but the touching time for the iron should not last too long, or the heat will ruin the fabrics directly.
6. Do not use strong bleach.
7. In winter or under severe weather (Tornado, Hurricane or Heavy Rain), please store your furniture such as cushions, pillows, parasols...etc. safely, and avoid the fabric damage caused by snow, strong wind or low temperature.
8. Machine washable and okay to spin dry. During the process, it must be in gentle mode, and the water temperature should not be higher than 30 degrees Celsius . The most recommended way is to let them air dry.



Functional Repair

Axroma / after-sales commitment:

In case the performance of water-repellency or stain-resistant fails to work normally after washing, our factory could provide the extra surface treatments for those fabrics themselves without any damages or deductibles.